



**Rieco-Titan Products, Inc.**

**965 Lambrecht Road ♦ Frankfort, IL 60423**

**(815)464-7400 ♦ Fax (815)469-4705**

email: [customerservice@riecotitan.com](mailto:customerservice@riecotitan.com)

[www.riecotitan.com](http://www.riecotitan.com)

### INSTRUCTIONS TO REPLACE POWER CORD WITH MALE PLUG

The power cord is hardwired into the motor and is not a "plug and play".

Unplug the powerhead from the camper corner.

Cut the existing power cord off leaving enough of the original cord on to splice to the new cord.

Splice the new cord onto the old cord. Please note that there are 2 wires, one wire has a ribbed surface and the other has a smooth surface. The ribbed one is positive and the smooth one is negative.

Waterproof the splice with a sealant appropriate for use on wiring or cable.